# FlatFrog

TeamTablet™ Flex
Quick Start Guide

Contents

1. Attach antennas

2. How to connect

Video Bar

HDMI OUT
HDMI IN

—— HDMI
- - - - USB

Interactive Display

① ② ③ ④ ⑤

USB-HDMI

Power adapter

Touch input
USB A - B

HDMI output

USB-A USB-B USB-C

EU
US
UK

Video Bar

HDMI in

Power

Touch

Interactive Display

HDMI out

LAN

USB3.0

② ④

① ③ ⑤

HDMI input
(not included)

Touch output
USB A - C

USB-HDMI

## 3. Optional mount with hangers

For more information (including more installation configurations) scan the QR code or follow the link below:

https://help.flatfrog.com/en/knowledge/teamtablet-flex